

**ROCK  
DOOR<sup>®</sup>**

## Technical Manual

REVISION 10.4



## Rockdoor Styles

Aspen	▶	4
Astoria	▶	5
Arcacia	▶	6
Byron	▶	7
Campus	▶	8
Carolina	▶	9
Classic	▶	10
Classic French Door	▶	11
Colonial	▶	12
Cottage spy view	▶	13
Cottage view light	▶	14
Dakota	▶	15
Diamond	▶	16
Dune Retreat	▶	17
Dune Vision	▶	18
English cottage	▶	19
Georgia	▶	20
Hudson	▶	21
Illinois	▶	22
Indiana	▶	23
Jacobean	▶	24
Kentucky	▶	25
Manhattan	▶	26
Montana	▶	27
Newark	▶	28
Portland	▶	29
Philadelphia	▶	30
Regency	▶	31
Stable diamond view	▶	32
Stable spy view	▶	33
Stable view light	▶	34
Tennessee	▶	35
Vermont	▶	36
Vogue	▶	37
Vogue French	▶	38
Warwick	▶	39
Windsor	▶	40

### MINIMUM SIZE OVERRIDES

- ▶ Minimum Sash Size Overrides [page 41](#)

### COLOURS

- ▶ Door and Frame Colour [page 43](#)

## Construction Details

### Sections

- ▶ Inner Frame Detail [page 44](#)
- ▶ Stable Door Centre Seal [page 45](#)
- ▶ Double/ French Door Centre Seal [page 46](#)

### Thresholds

- ▶ ALI Threshold Detail [page 47](#)
- ▶ PVC Threshold Detail [page 48](#)
- ▶ Cill Detail [page 49](#)
- ▶ Tie Bar Detail [page 51](#)
- ▶ Sealing a threshold to a cill or tie bar [page 52](#)

### Frame

- ▶ Outer Frame Detail [page 53](#)
- ▶ Add On / Frame Extension [page 54](#)
- ▶ Side Frame Detail [page 55](#)
- ▶ Coupling Bar Detail [page 57](#)
- ▶ Side Frame / Coupling Bar Max Sizes [page 58](#)
- ▶ Side Frame Min Sizes / Transoms [page 60](#)
- ▶ Moulded Panels [page 61](#)
- ▶ Clear Opening [page 62](#)
- ▶ Internal Floor Level Clearance [page 63](#)

### Locks

- ▶ 2 Hook Lock [page 2](#)
- ▶ 4 Hook Lock [page 104](#)
- ▶ AV Options [page 105](#)
- ▶ Electric Latch Release [page 109](#)
- ▶ Switch Latch [page 108](#)
- ▶ Instant Lock Heritage Plus [page 106](#)
- ▶ Cylinder [page 110](#)
- ▶ Emergency Exit Lock [page 112](#)

### Hinge

- ▶ Hinge [page 88](#)
- ▶ Open Out Hinge [page 89](#)

### Lever Handles

- ▶ Standard Lever Handle [page 64](#)
- ▶ Escutcheon v Lever Handle Prep [page 65](#)
- ▶ Stainless Steel Lever Handle [page 66](#)
- ▶ Rose Handle Prep [page 67](#)
- ▶ European Rose Handle [page 68](#)
- ▶ Curved Rose Handle [page 69](#)
- ▶ Twist Lever Handle [page 70](#)
- ▶ Arched Lever Handle [page 71](#)

### Bar Handles

- ▶ In line Bar Handle Details [page 72](#)
- ▶ Offset Bar Handle Details [page 45](#)
- ▶ Mitred Bar Handle Details [page 76](#)
- ▶ Square 1200/900 Bar Handle [page 78](#)
- ▶ Round In Line 600/1200/900 Bar Handle [page 79](#)
- ▶ Square Offset 1200 Bar Handle [page 80](#)
- ▶ Round Offset 1200 Bar Handle [page 81](#)
- ▶ Mitered 900 Bar Handle [page 82](#)
- ▶ Back to Back Fixing Kit [page 83](#)

### Letterplates

- ▶ Standard Letterplate [page 84](#)
- ▶ Stainless Steel Letterplate [page 85](#)
- ▶ Architectural letterplate [page 86](#)
- ▶ TS008 Letterplate [page 87](#)

### Furniture

- ▶ Bull Ring Knockers [page 90](#)
- ▶ Cat Flap [page 93](#)
- ▶ Restrictor Details [page 94](#)
- ▶ Furniture Colour Options [page 95](#)
- ▶ Furniture Positions [page 97](#)


### Door Pulls

- ▶ Door Pull [page 92](#)
- ▶ Round Knob [page 91](#)

### OTHER INFORMATION

- ▶ Secured By Design [page 115](#)
- ▶ PAS24 [page 113](#)
- ▶ Energy Ratings [page 116](#)
- ▶ Condensation [page 117](#)
- ▶ Replacement Parts [page 122](#)
- ▶ Order Form [page 120](#)
- ▶ Installation Tolerances [page 121](#)

New Forest Texture & 26mm Unit



Door Sash

**Width**  
 Max: 908mm  
 Min: 674mm

**Height**  
 Max: 2098mm  
 Min: 1789mm

Profile Dimensions:  
**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**


**Width**  
**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**  
**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**  
 Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

PRESS GLAZING  
**UNIT THICKNESS:** 26  
**UNIT SIZE:** 177 x 729  
**APERTURE:** 140x 690

New Forest Texture & 26mm Unit



Door Sash

**Width**  
 Max: 908mm  
 Min: 760mm

**Height**  
 Max: 2098mm  
 Min: 1942mm

Profile Dimensions:  
**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**

**Width**  
**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**  
**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**  
 Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

PRESS GLAZING  
**UNIT THICKNESS:** 26  
**UNIT SIZE:** 562 x 468  
**APERTURE:** 530x 430

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 53](#) ►

PVC-U Thresholds [page 48](#) ►

Ali Thresholds / Tie Bars [page 47](#) ►

Cills [page 49](#) ►

Add On / Frame Extensions [page 54](#) ►



Door Sash

**Width**

Max: 908mm  
Min: 710mm

**Height**

Max: 2098mm  
Min: 1763mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

PRESS GLAZING

UNIT THICKNESS: 22

UNIT SIZE: 246 x 668

APERTURE: 208 x 630


PRESS BEAD GLAZING

UNIT THICKNESS: 24

UNIT SIZE: 207 x 632

APERTURE: 182 x 604

New Forest Texture & 26mm Unit



Door Sash

**Width**

Max: 908mm  
Min: 783mm

**Height**

Max: 2098mm  
Min: 1940mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)


Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

PRESS GLAZING

UNIT THICKNESS: 26

UNIT SIZE: 260 x 958

APERTURE: 222 x 920



Door Sash

**Width**

Max: 908mm  
Min: 713mm

**Height**

Max: 2098mm  
Min: 1808mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

Unit Thickness: 22

Unit Size: 185 X 630

Aperture: 148 X 590

Press Bead Glazing

Unit Thickness: 24

Unit Size: 185 X 630

Aperture: 148 X 590

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ▶

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 53](#) ▶

PVC-U Thresholds [page 48](#) ▶

Ali Thresholds / Tie Bars [page 47](#) ▶

Cills [page 49](#) ▶

Add On / Frame Extensions [page 54](#) ▶



Door Sash

**Width**

Max: 908mm  
Min: 769mm

**Height**

Max: 2098mm  
Min: 1758mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**Height**

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

Unit Thickness: 22

Unit Size: 560 X 275

Aperture: N/A


Press Bead Glazing

Unit Thickness: 24

Unit Size: 490 X 225

Aperture: 452 X 192





Door Sash

Width

Max: 908mm  
Min: 808mm

Height

Max: 2098mm  
Min: 1799mm Lock override 1893mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

Width

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

Height

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing


Unit Thickness: 22

Unit Size: 599 X 1390

Aperture: 565 X 1356

Press Bead Glazing

N/A



Door Sashes

Width

Max: 908+7+908 = 1823mm  
Min: 808+7+808 = 1623mm

Height

Max: 2098mm  
Min: 1799mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

Height

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Bead Glazing

N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ▶

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 53](#) ▶


PVC-U Thresholds [page 48](#) ▶

Ali Thresholds / Tie Bars [page 47](#) ▶

Cills [page 49](#) ▶

Add On / Frame Extensions [page 54](#) ▶





Door Sash

**Width**

Max: 908mm  
Min: 729mm

**Height**

Max: 2098mm  
Min: 1728mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

N/A

Press Bead Glazing

N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ▶

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 53](#) ▶

PVC-U Thresholds [page 48](#) ▶

Ali Thresholds / Tie Bars [page 47](#) ▶

Cills [page 49](#) ▶

Add On / Frame Extensions [page 54](#) ▶



Door Sash

**Width**

Max: 908mm  
Min: 673mm

**Height**

Max: 2098mm  
Min: 1748mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**Height**

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

Unit Thickness: 22

Unit Size: 150 X 300

Aperture: 109 X 252

Press Bead Glazing


Unit Thickness: 24

Unit Size: 114 X 255

Aperture: 85 X 226



## COTTAGE VIEW LIGHT



### Door Sash

#### Width

Max: 908mm  
Min: 708mm

#### Height

Max: 2098mm  
Min: 1788mm

#### Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN** = **20mm**

**Ali low threshold open OUT** = **17mm**

**Cill** = **30mm**

#### Width

##### 72 Frame

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

##### 52 Frame

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

#### Height

##### 72 Frame low threshold open IN

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

##### 52 Frame low threshold open IN

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

#### Double Door Width 72mm Frame

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

#### Press Glazing

Unit Thickness: 22

Unit Size: 485 X 625

Aperture: 436 X 576

#### Press Bead Glazing

Unit Thickness: 24

Unit Size: 440 X 580

Aperture: 410 X 550

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 53](#) ►

PVC-U Thresholds [page 48](#) ►


Ali Thresholds / Tie Bars [page 47](#) ►

Cills [page 49](#) ►

Add On / Frame Extensions [page 54](#) ►

## DAKOTA

## New Forest Texture



### Door Sash

#### Width

Max: 908mm  
Min: 679mm

#### Height

Max: 2098mm  
Min: 1768mm

#### Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN** = **20mm**

**Ali low threshold open OUT** = **17mm**

**Cill** = **30mm**

#### Width

##### 72 Frame

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

##### 52 Frame

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

#### Height

##### 72 Frame low threshold open IN

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

##### 52 Frame low threshold open IN

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)


#### Double Door Width 72mm Frame

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

ROCK  
DOOR

► [Index pages 2-3](#)



Door Sash

**Width**

Max: 908mm  
Min: 696mm

**Height**

Max: 2098mm  
Min: 1764mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

Unit Thickness: 22

Unit Size: 320 X 435

Aperture: 277 X 371

Press Bead Glazing

N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 53](#) ►

PVC-U Thresholds [page 48](#) ►

Ali Thresholds / Tie Bars [page 47](#) ►

Cills [page 49](#) ►

Add On / Frame Extensions [page 54](#) ►



New Dune Texture

Door Sash

**Width**

Max: 908mm  
Min: 679mm

**Height**

Max: 2098mm  
Min: 1880mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

Unit Thickness: 22


Unit Size: 118 X 1518

Aperture: 80 X 1480

Press Bead Glazing

N/A





Door Sash

**Width**  
 Max: 908mm  
 Min: 679mm

**Height**  
 Max: 2098mm  
 Min: 1880mm

Profile Dimensions:  
**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**

**Width**  
**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**  
**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**  
 Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing  
 Unit Thickness: 22  
 Unit Size: 238 X 1518  
 Aperture: 200 X 1480


Press Bead Glazing  
 N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:

- Door Outer Frame [page 53](#) ►
- PVC-U Thresholds [page 48](#) ►
- Ali Thresholds / Tie Bars [page 47](#) ►
- Cills [page 49](#) ►
- Add On / Frame Extensions [page 54](#) ►



Door Sash  
**Width**  
 Max: 908mm  
 Min: 679mm

**Height**  
 Max: 2098mm  
 Min: 1796mm

Profile Dimensions:  
**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**

**Width**  
**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)


**Height**  
**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**  
 Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing  
 Unit Thickness: 22  
 Unit Size: 192 X 447  
 Aperture: 152 X 413

Press Bead Glazing  
 N/A





Door Sash

**Width**  
 Max: 908mm  
 Min: 724mm

**Height**  
 Max: 2098mm  
 Min: 1797mm

Profile Dimensions:  
**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**

**Width**  
**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**  
**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**  
 Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

**Press Glazing**  
 Unit Thickness: 22  
 Unit Size: 512 X 1008  
 Aperture: 462X (752 /961/752)

**Press Bead Glazing**  
 N/A


Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:

- Door Outer Frame [page 53](#) ►
- PVC-U Thresholds [page 48](#) ►
- Ali Thresholds / Tie Bars [page 47](#) ►
- Cills [page 49](#) ►
- Add On / Frame Extensions [page 54](#) ►

New Forest Texture & 26mm Unit



Door Sash

**Width**  
 Max: 908mm  
 Min: 674mm

**Height**  
 Max: 2098mm  
 Min: 1841mm

Profile Dimensions:  
**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali low threshold open IN = 20mm**  
**Ali low threshold open OUT = 17mm**  
**Cill = 30mm**


**Width**  
**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**  
**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**  
 Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

**PRESS GLAZING**  
**UNIT THICKNESS:** 26  
**UNIT SIZE:** 177 x 1627  
**APERTURE:** 140x 1590





Door Sash

**Width**

Max: 908mm  
Min: 768mm

**Height**

Max: 2098mm  
Min: 1808mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

Unit Thickness: 22

Unit Size: 240 X 1067 (2 Off)

Aperture: 202 X 1030 (2 Off)

Press Bead Glazing

N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 53](#) ►

PVC-U Thresholds [page 48](#) ►

Ali Thresholds / Tie Bars [page 47](#) ►

Cills [page 49](#) ►

Add On / Frame Extensions [page 54](#) ►



Door Sash

**Width**

Max: 908mm  
Min: 768mm

**Height**

Max: 2098mm  
Min: 1808mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)


Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)





Door Sash

**Width**

Max: 908mm  
Min: 753mm

**Height**

Max: 2098mm  
Min: 1801mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

Unit Thickness: 22

Unit Size: 220 X 910

Aperture: 180 X 866

Press Bead Glazing

Unit Thickness: 24

Unit Size: 188 X 875

Aperture: 155 X 842

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ▶

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 53](#) ▶

PVC-U Thresholds [page 48](#) ▶

Ali Thresholds / Tie Bars [page 47](#) ▶

Cills [page 49](#) ▶

Add On / Frame Extensions [page 54](#) ▶



Door Sash

**Width**

Max: 908mm  
Min: 768mm

**Height**

Max: 2098mm  
Min: 1801mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

Unit Thickness: 22

Unit Size: 560 X 912

Aperture: 508 X 867


Press Bead Glazing

Unit Thickness: 24

Unit Size: 516 X 875

Aperture: 482 X 840





Door Sash

**Width**

Max: 908mm  
Min: 679mm

**Height**

Max: 2098mm  
Min: 1800mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)


Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

Unit Thickness: 22

Unit Size: 212 X 212

Aperture: 172 X 172



Door Sash

**Width**

Max: 908mm  
Min: 684mm

**Height**

Max: 2098mm  
Min: 1797mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

Unit Thickness: 22

Unit Size: 365 X 862

Aperture: 320 X 819

Press Bead Glazing

N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 53](#) ►


PVC-U Thresholds [page 48](#) ►

Ali Thresholds / Tie Bars [page 47](#) ►

Cills [page 49](#) ►

Add On / Frame Extensions [page 54](#) ►





Door Sash

Width

Max: 908mm  
Min: 769mm

Height

Max: 2098mm  
Min: 1809mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

Width

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

Height

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

Unit Thickness: 22

Unit Size: 547 X 447

Aperture: 512 X 409

Press Bead Glazing

N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 53](#) ►

PVC-U Thresholds [page 48](#) ►

Ali Thresholds / Tie Bars [page 47](#) ►

Cills [page 49](#) ►

Add On / Frame Extensions [page 54](#) ►



Door Sash

Width

Max: 908mm  
Min: 768mm

Height

Max: 2098mm  
Min: 1808mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

Width

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

Height

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

Unit Thickness: 22


Unit Size: 547 X 1047

Aperture: 512 X 1011

Press Bead Glazing

N/A





Door Sash

**Width**

Max: 908mm  
Min: 696mm

**Height**

Max: 2098mm  
Min: 1764mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

N/A

Press Bead Glazing

Unit Thickness: 24

Unit Size: 440 X 580

Aperture: 410 X 550

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ▶

The overall frame dimensions can be increased or reduced by using other profiles:


Door Outer Frame [page 53](#) ▶

PVC-U Thresholds [page 48](#) ▶

Ali Thresholds / Tie Bars [page 47](#) ▶

Cills [page 49](#) ▶

Add On / Frame Extensions [page 54](#) ▶



Door Sash

**Width**

Max: 908mm  
Min: 769mm

**Height**

Max: 2098mm  
Min: 1728mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

Unit Thickness: 22

Unit Size: 230 X 175


Aperture: 187 X 140

Press Bead Glazing

N/A



## STABLE DIAMOND VIEW



### Door Sash

#### Width

Max: 908mm  
Min: 696mm

#### Height

Max: 2014mm  
Min: 1708mm

#### Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

#### Width

##### 72 Frame

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

##### 52 Frame

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

#### Height

##### 72 Frame low threshold open IN

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

##### 52 Frame low threshold open IN

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

#### Double Door Width 72mm Frame

N/A

#### Press Glazing


Unit Thickness: 22

Unit Size: 320 X 435

Aperture: 277 X 371

#### Press Bead Glazing

N/A



Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 53](#) ►


PVC-U Thresholds [page 48](#) ►

Ali Thresholds / Tie Bars [page 47](#) ►

Cills [page 49](#) ►

Add On / Frame Extensions [page 54](#) ►

## STABLE SPY VIEW



### Door Sash

#### Width

Max: 908mm  
Min: 673mm

#### Height

Max: 2014mm  
Min: 1668mm

#### Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

#### Width

##### 72 Frame

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

##### 52 Frame

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

#### Height

##### 72 Frame low threshold open IN

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

##### 52 Frame low threshold open IN

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

#### Double Door Width 72mm Frame

N/A

#### Press Glazing


Unit Thickness: 22


Unit Size: 150 X 300

Aperture: 109 X 252

#### Press Bead Glazing

N/A





**Door Sash**  
**Width**  
 Max: 908mm  
 Min: 708mm

**Height**  
 Max: 2014mm  
 Min: 1708mm

Profile Dimensions:  
**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali** low threshold open **IN** = **20mm**  
**Ali** low threshold open **OUT** = **17mm**  
**Cill** = **30mm**


**Width**  
**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**  
**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**  
 N/A

**Press Glazing**  
 Unit Thickness: 22  
 Unit Size: 485 X 625  
 Aperture: 436 X 576

**Press Bead Glazing**  
 N/A




Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ▶

The overall frame dimensions can be increased or reduced by using other profiles:

- Door Outer Frame [page 53](#) ▶
- PVC-U Thresholds [page 48](#) ▶
- Ali Thresholds / Tie Bars [page 47](#) ▶
- Cills [page 49](#) ▶
- Add On / Frame Extensions [page 54](#) ▶



**Door Sash**  
**Width**  
 Max: 908mm  
 Min: 748mm

**Height**  
 Max: 2098mm  
 Min: 1748mm

Profile Dimensions:  
**72 Frame:** 52mm+4mm air gap = **56mm**  
**52 Frame:** 32mm+4mm air gap = **36mm**  
**Ali** low threshold open **IN** = **20mm**  
**Ali** low threshold open **OUT** = **17mm**  
**Cill** = **30mm**

**Width**  
**72 Frame**  
 Max = (Max sash width + 56mm + 56mm)  
 Min = (Min sash width + 56mm + 56mm)  
**52 Frame**  
 Max = (Max sash width + 36mm + 36mm)  
 Min = (Min sash width + 36mm + 36mm)

**Height**  
**72 Frame low threshold open IN**  
 Max = (Max sash height + 56mm + 20mm)  
 Min = (Min sash height + 56mm + 20mm)  
**52 Frame low threshold open IN**  
 Max = (Max sash height + 36mm + 20mm)  
 Min = (Min sash height + 36mm + 20mm)


**Double Door Width 72mm Frame**  
 Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)  
 Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

**Press Glazing**  
 Unit Thickness: 22  
 Unit Size: 556 X R276  
 Aperture: 520 X R240

Unit Size: 226 X 496 (2 Off)  
 Aperture: 190 X 460 (2 Off)

**Press Bead Glazing**  
 N/A





Door Sash

**Width**

Max: 908mm  
Min: 675mm

**Height**

Max: 2098mm  
Min: 1850mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing


Unit Thickness: 22

Unit Size: 200 X 1510

Aperture: 163 X 1472

Press Bead Glazing

N/A



Door Sash

**Width**

Max: 908mm  
Min: 675mm

**Height**

Max: 2098mm  
Min: 1850mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

Unit Thickness: 22

Unit Size: 387 X 1323

Aperture: 352 X 1288

Press Bead Glazing

N/A

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ▶

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 53](#) ▶


PVC-U Thresholds [page 48](#) ▶

Ali Thresholds / Tie Bars [page 47](#) ▶

Cills [page 49](#) ▶

Add On / Frame Extensions [page 54](#) ▶





Door Sash2

**Width**

Max:  $908+7+908 = 1823\text{mm}$   
 Min:  $675+7+675 = 1357\text{mm}$

**Height**

Max: 2098mm  
 Min: 1850mm Lock override 1893mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width +56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width +56mm + 56mm + 7mm)

Press Glazing


Unit Thickness: 22

Unit Size: 387 X 1323


Aperture: 352 X 1288

Press Bead Glazing

N/A



New Forest Texture & 26mm Unit



Door Sash

**Width**

Max: 908mm  
 Min: 769mm

**Height**

Max: 2098mm  
 Min: 1897mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width +56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width +56mm + 56mm + 7mm)

PRESS GLAZING

UNIT THICKNESS: 26

UNIT SIZE: 177 x 977

APERTURE: 140x 940

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ►

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 53](#) ►


PVC-U Thresholds [page 48](#) ►

Ali Thresholds / Tie Bars [page 47](#) ►

Cills [page 49](#) ►

Add On / Frame Extensions [page 54](#) ►





Door Sash

**Width**

Max: 908mm  
Min: 748mm

**Height**

Max: 2098mm  
Min: 1801mm

Profile Dimensions:

**72 Frame:** 52mm+4mm air gap = **56mm**

**52 Frame:** 32mm+4mm air gap = **36mm**

**Ali low threshold open IN = 20mm**

**Ali low threshold open OUT = 17mm**

**Cill = 30mm**

**Width**

**72 Frame**

Max = (Max sash width + 56mm + 56mm)

Min = (Min sash width + 56mm + 56mm)

**52 Frame**

Max = (Max sash width + 36mm + 36mm)

Min = (Min sash width + 36mm + 36mm)

**Height**

**72 Frame low threshold open IN**

Max = (Max sash height + 56mm + 20mm)

Min = (Min sash height + 56mm + 20mm)

**52 Frame low threshold open IN**

Max = (Max sash height + 36mm + 20mm)

Min = (Min sash height + 36mm + 20mm)

**Double Door Width 72mm Frame**

Max = (Max sash width + Max sash width + 56mm + 56mm + 7mm)

Min = (Min sash width + Min sash width + 56mm + 56mm + 7mm)

Press Glazing

Unit Thickness: 22

Unit Size: 530 X 910

Aperture: 495 X 872

Press Bead Glazing

Unit Thickness: 24

Unit Size: 495 X 875

Aperture: 462 X 842

Lock options and double doors and French doors can override the minimum sash heights stated above:

Minimum Sash Size Overrides [page 41](#) ▶

The overall frame dimensions can be increased or reduced by using other profiles:

Door Outer Frame [page 53](#) ▶

PVC-U Thresholds [page 48](#) ▶

Ali Thresholds / Tie Bars [page 47](#) ▶

Cills [page 49](#) ▶

Add On / Frame Extensions [page 54](#) ▶

**2 Hook Lever Lock and Key Lock**

Minimum sash height is 1880mm

Below 1880mm a 3 hook lock will be used (Charged for a 4 hook lock)

**Double Doors**

Minimum sash height is 1996mm

Below 1996mm a 3 hook lock will be used (Charged for a 4 hook lock)

**French Doors**

Minimum sash height is 1893mm




## Door and Frame Colour

Where the sash and frame meet on the flush side, there is a chamfer on the door which is visible. It is more noticeable when the door and frame are dark colours.


### Open Out Doors with matching sash and frame colours

External View



### Open In Doors with matching sash and frame colours

Internal View




## Door and Frame Colour Options



**WHITE**  
Available with matching outerframe.



**CREAM (RAL9001)**  
Available with matching outerframe.



**BLACK (RAL8022)**  
Available with matching outerframe.



**ANTHRACITE GREY (RAL7016)**  
Available with matching outerframe.




**SLATE GREY (RAL7015)**  
Available with matching outerframe.




**AGATE GREY (RAL7038)**  
Available with matching outerframe.



**CHARTWELL GREEN**  
Available with matching outerframe.




**ROSEWOOD**  
Available with matching outerframe.




**LIGHT OAK**  
Available with matching outerframe.



**IRISH OAK**  
Available with matching outerframe.



**SAPPHIRE BLUE (RAL5011)**



**EMERALD GREEN (RAL6009)**




**RUBY RED (RAL3011)**




**PEBBLE GREY (RAL7032)**  
Available with matching outerframe.  
Large face only.




**Inner Frame Detail**



**Stable Door Centre Seal**




## French / Double Door Centre Seal




### Open IN Aluminium Threshold

Drip bar and gasket carrier one piece, colour matched to the furniture.




## Threshold Detail





Face fix drip bar with separate gasket carrier, colour matched to the door.



### Open OUT Aluminium Threshold



#### Gasket Codes


-  R149
-  Comes with the carrier
-  R149A
-  R149B

#### PART M

Thresholds on this page are Part M compliant. They have an upstand of 15mm or less and give easy and safe access for everyone, including wheelchairs and people with limited mobility.  
\*Please note that Part M includes additional accessibility requirements beyond the door threshold.

### 72mm PVC-U Threshold


### Threshold Detail



A= Face Drainage  
(Slots 5mm x 35mm)

B= Concealed Drainage

### 52mm PVC-U Threshold




A= Face Drainage  
(Slots 5mm x 35mm)

B= Concealed Drainage


### Cill Detail

If a cill is required on a Rockdoors with a sideframe a reinforced cill **must** be used.

#### 95mm Cill Art.546360




#### Reinforcement Art.251355




50mm x 15mm

#### 150mm Cill Art.246330



#### Reinforcement Art.324971




30mm x 20mm




Face A & Face B used to identify foiled face

If a cill is required on a Rockdoors with a sideframe a reinforced cill **must** be used.



**180mm Cill**  
**Art.246340**  
 Reinforcement 30 x 20



**Reinforcement for BOTH 180mm and 225mm cill**  
**Art.324971**  
 50 x 15  
 Reinforcement 30 x 20




**225mm Cill**  
**Art.503940**  
 Reinforcement 30 x 20




Face A & Face B used to identify foiled face

**Tie Bar 9mm x 85mm** (Max 3m in length)




**Aluminium**  
 Available in Gold and Silver

**Tie Bar 15mm x 114mm** (Max 3m in length)




Tie bars can be used with all threshold types and can be positioned to suit the application.

**Examples using an open in low aluminium threshold.**




## Sealing a threshold to a cill or tie bar



The position of the silicone seal is marked in red.

On low aluminium thresholds ensure all drain holes are not blocked with silicone.




### NOTE:

The full perimeter of the door and under the cill / tie bar must be externally sealed in addition to the sealing listed above.


## Outer Frame Detail

### 72mm Outer Frame



52

### 52mm Outer Frame




32




## Add On / Frame Extension

### 45mm Add On / Frame Extension




### 15mm Add On / Frame Extension




## Side Frame Detail

### 72mm Side Frame



### 52mm Side Frame





## Coupling Bar Detail

### Heavy Weight Coupler (10mm wide)

#### Protruding

Recommended for the higher exposure category. The coupler protrudes this makes it the strongest design of all couplers offered.




CODE WWL153  
 IXX (cm) 27.95  
 IYY (cm) 0.79  
 DEDUCTION 5mm Per Frame

### Medium Weight Coupler (20mm wide)

#### Flush Fitting

Recommended where a higher exposure category or larger side frames is requested and the couplers remain Flush to the door frame





CODE WWL106  
 IXX (cm) 24.5  
 IYY (cm) 2.4  
 DEDUCTION 10mm Per Frame

## Coupling Bar Detail

### Light Weight Coupler (10mm wide)

#### Flush Fitting



Recommended in lower exposure zones and for the narrower side frames.



CODE WWL150  
 IXX (cm) 9.97  
 IYY (cm) 0.40  
 DEDUCTION 5mm Per Frame

### 1.5mm Coupler (1.5mm wide) PVC-U

**Only** use on single door fanlights




CODE PFC70  
 IXX (cm) 0  
 IYY (cm) 10  
 DEDUCTION 0.75mm Per Frame




## Side Frame / Coupling Bar Max Sizes

72mm Reinforced Outer Frame to achieve 800PA.

**Heavy Duty** (10mm wide)  
Rigidity : **Very High**



The door size cannot be larger than 900mm




MAX Sizes for Side Frames constructed from 72mm Reinforced Outer Frame using Heavy Duty Coupler


## Side Frame / Coupling Bar Max Sizes

52mm Reinforced Outer Frame to achieve 800PA.

**Heavy Duty** (10mm wide)  
Rigidity : **Very High**




The door size cannot be larger than 900mm x 2070mm




MAX Sizes for Side Frames constructed from 72mm Reinforced Outer Frame using Heavy Duty Coupler

**Medium Duty Coupler** (20mm Wide)  
Rigidity : **High**




The door size cannot be larger than 900mm x 2070mm




MAX Sizes for Side Frames constructed from 72mm Reinforced Outer Frame using Medium Duty Coupler

**Medium Duty Coupler** (20mm Wide)  
Rigidity : **High**




The door size cannot be larger than 900mm x 2070mm




MAX Sizes for Side Frames constructed from 72mm Reinforced Outer Frame using Medium Duty Coupler

**Light Duty Coupler** (10mm wide)  
Rigidity : **Standard**




The door size cannot be larger than 900mm x 2070mm




MAX Sizes for Side Frames constructed from 72mm Reinforced Outer Frame using Light Duty Coupler

**Light Duty Coupler** (10mm wide)  
Rigidity : **Standard**



The door size cannot be larger than 900mm x 2070mm



MAX Sizes for Side Frames constructed from 72mm Reinforced Outer Frame using Light Duty Coupler

It is the installers responsibility to ensure that the products are fit for purpose for the environment in which they are installed and the correct level of operational performance is achieved.

It is the installers responsibility to ensure that the products are fit for purpose for the environment in which they are installed and the correct level of operational performance is achieved.

**Sideframe with MIDRAIL**

72mm outer with 105.5 Midrail: **min width =323.5mm**  
 72mm outer with 69 Midrail: **min width =360mm**  
 52mm outer with 69 Midrail: **min width =320mm**


**Sideframe with NO Midrail GROOVED**

72mm outer: **min width =295mm**  
 52mm outer: **min width =275mm**


**Sideframe with NO Midrail KNIFED OFF by hand**

72mm outer: **min width =190mm**  
 52mm outer: **min width =190mm**


Standard and the stainless steel option letterplates cannot be fitted into midrails.



**Door T Sash / Midrail 105.5mm**  
 Standard Midrail in sideframes  
**Art.546635**




**Slim Transom / Mullion T 69mm**  
 Standard Mullion in Fanlights  
**Art.546085**



**Co-extruded Glazing Bead 18.5**  
 For 28mm sealed units  
**Art.546572**


**DOUBLE MOULDED PANELS**

MAX SIZE: w785 x h950  
 MIN SIZE: w620 x h580




**SINGLE MOULDED PANELS**

MAX SIZE: w420 x h950  
 MIN SIZE: w290 x h580



72mm Outer Frame




CLEAR OPENING=  
Door Frame width -194mm

Example:  
A Door frame width of 900mm has a  
clear opening of 706mm

*To comply with Document M, a private or communal entrance  
must have a clear opening greater than 775mm.*

52mm Outer Frame




CLEAR OPENING=  
Door Frame width -154mm

Example:  
A Door frame width of 900mm has a  
clear opening of 746mm

*To comply with Document M, a private or communal entrance  
must have a clear opening greater than 775mm.*

INTERNAL STEP




INTERNAL STEP CLEARANCE  
= Sash width + 15mm

15mm Hinge Swing


For **72mm** Profile Sash Width = Overall Frame Width -112

For **52mm** Profile Sash width = Overall Frame Width -72



### Standard Lever Handle




### Lever Handle / Escutcheon Prep



## Stainless Steel Handle




### Important fitting Detail



Insert the spindle so the exposed dish (or spindle groove) as shown in green faces the grub screw. Then tighten the grub screw clockwise to 'splay' the spindle and secure the handle in place.

Doing this **external** and **internal** ensures the handles are secured to the spindle.

## Rose Handle Prep



### Hole position Jig




Its important the jig lines up with the spindle hole on the door.



Its important the jig lines up with the spindle hole on the door.



When everything is lined up, place the pin into the jig and spindle hole to lock the position.







Drill four holes with a 3.2mm drill bit see picture below holding the jig firmly.




You MUST DRILL INTO THE SKIN AND THE ALUMINIUM REPEAT THE PROCESS ON THE OTHER SIDE OF THE DOOR.

## European Rose Handle





### Important fitting Detail




Insert the spindle so the exposed dish (or spindle groove) as shown in green faces the grub screw. Then tighten the grub screw clockwise to 'splay' the spindle and secure the handle in place.

Doing this **external** and **internal** ensures the handles are secured to the spindle.


## Curved Rose Handle



Cover Plate



### Important fitting Detail






Insert the spindle so the exposed dish (or spindle groove) as shown in green faces the grub screw. Then tighten the grub screw clockwise to 'splay' the spindle and secure the handle in place.


Doing this **external** and **internal** ensures the handles are secured to the spindle.

## Twist Lever Handle

### Handle Prep



### Important fitting Detail






Insert the spindle so the exp (or spindle groove) as show faces the grub screw. Then the grub screw clockwise to the spindle and secure the place.

Doing this **external** and **inte** the handles are secured to


Tighten the grub screw.

## Arched Lever Handle

### Handle Prep



### Important fitting Detail



Insert the spindle so the exposed dish (or spindle groove) as shown in green faces the grub screw. Then tighten the grub screw clockwise to 'splay' the spindle and secure the handle in place.


Doing this **external** and **internal** ensures the handles are secured to the spindle.

Tighten the grub screw.

**In Line Bar Handle**


600mm, 900mm and 1200mm Fitting Position

**Vogue**




Centred with the glass

**Vermont**




Centred with the glass

**Indiana**




Centred with the mouldings

**Dakota**




Centred with the mouldings

**Manhattan**



Starting datum bottom moulding

**Hudson**



Centred with the glass

**In line bar handles** are fitted **115mm** from the edge of the door to the centre of the fixing hole.

**In Line Bar Handle**


600mm, 900mm and 1200mm Fitting Position

**Dune Vision**




Centred with the glass

**Dune Retreat**



Centred with the glass

**Aspen**




Centred with the mouldings

**In line bar handles** are fitted **115mm** from the edge of the door to the centre of the fixing hole.

## Offset Bar Handle


### 900mm and 1200mm Fitting Position

Vogue




Centred with the glass

Vermont




Centred with the glass

Indiana




Centred with the mouldings

Dakota




Centred with the mouldings

Manhattan



**Off set bar handles** are fitted **45mm** from the edge of the door to the centre of the fixing hole.

Hudson




Centred with the glass

## Offset Bar Handle


### 900mm and 1200mm Fitting Position

Dune Vision




Centred with the glass

Dune Retreat



Centred with the glass

Aspen




Centred with the mouldings

**Off set bar handles** are fitted **45mm** from the edge of the door to the centre of the fixing hole.

## Mitred Bar Handle


### 900mm Fitting Position

#### Vogue



Centred with the glass


#### Vermont



Minimum sash width  
with mitred bar handle is  
**755mm**

Centred with the glass


#### Indiana



Minimum sash width  
with mitred bar handle is  
**820mm**


Centred with the mouldings

#### Dakota



Centred with the mouldings


#### Manhattan



#### Mitred bar handles

are fitted **115mm** from the edge of the door to the centre of the fixing hole.

#### Hudson




Minimum sash width  
with In line bar handle is  
**755mm**

Centred with the glass

## Mitred Bar Handle


### 900mm Fitting Position

#### Dune Vision




Centred with the glass

#### Dune Retreat



Centred with the glass

#### Aspen



Minimum sash width  
with In line bar handle is  
**755mm**

Centred with the mouldings



#### Mitred bar handles

are fitted **115mm** from the edge of the door to the centre of the fixing hole.

**Square Bar 1200mm / Square Bar 900mm**

**SIZE:1200 Bar Handle**  
**A=1200mm**  
**B=1000mm**  
**C=100mm**

**SIZE:900 Bar Handle**  
**A=900mm**  
**B=700mm**  
**C=100mm**





**Round Bar 600mm, 900mm and 1200mm**

**SIZE:600mm**  
**A=600mm**  
**B=400mm**  
**C=100mm**



**SIZE:900mm**  
**A=900mm**  
**B=700mm**  
**C=100mm**

**SIZE:1200mm**  
**A=1200mm**  
**B=1000mm**  
**C=100mm**





SIZE:  
**A=1200mm**  
**B=1000mm**  
**C=100mm**

### Square Bar 1200mm (Offset)




SIZE:  
**A=1200mm**  
**B=1000mm**  
**C=100mm**


### Round Bar 1200mm (Offset)



**SIZE:**  
**A=930mm**  
**B= 900mm**



## Mitre Bar 900mm



## Back to Back Fixing Kit


### Fitting Instructions

(Do the same on the top and the bottom fixing position)


The metal washers can be used if required they fit between the brass ferrules and the Rockdoor.

1. From the inside slide the non threaded brass ferrule over the fixing bolt so the counter sunk head fits into the counter sink of the ferrule.


Slide the 8mm fixing bolt through the pre drilled hole in the Rockdoor.




2. Screw the threaded ferrule to the fixing bolt from the outside.



3. Fit the handles in position




4. Tighten all the grub screws to secure.




### Standard Letterplate

Meets the requirements of BS EN 1670:2007 Grade 5 (480 hours)  
 Flap cycle tested to 30,000 cycles  
 Conforms to the requirements of BS EN 13724: 2002  
 Zinc construction with hardex coating.




### Stainless Steel Letterplate

Cycle tested to 20,000 cycles  
 Corrosion tested in excess of 1,000 hours based on BS EN 1670  
 304 stainless steel construction




### Stainless Steel Contemporary Letterplate

- Achieved 'Best in Class' BS6375-1 Weather Test results against air, wind and water.  
 Weather Test : Air Permeability: Class 4, Water Tightness: Class A9, Wind Resistance: Class 5
- Integral gaskets, brushes and telescopic liner for enhanced weather and draught protection.
- Built-in inner security flap helps prevent 'fishing'.
- Manufactured from 316 Grade Stainless Steel.
- Ideal for use where corrosion levels are high such as coastal environments.



### Aperture Detail




### Fitting in the bottom rail

Check online using the portal as it is sash height dependant.


**Not available under the glass on the Georga, the Montana and the Newark.**

Architectural letterplate




TS008 Letterplate

Cycle tested to 20,000 cycles  
 Corrosion tested in excess of 1,000 hours based on BS EN 1670  
 White PVC-U internal  
 304 stainless steel construction external  
 Concealed hinge mechanism for attack resistance



Sideframe Letterplate

180 Opening  
 Black plastic frame  
 Aperture size 247mm x 28mm







# Hinge

## Rockdoor Standard Hinge

Adjustable using a 4mm allen key.

Up/Down +/-3mm In/Out +/-2mm Left/Right +/-2mm







# Open Out Hinge

## Open Out Hinge

Adjustable using a 4mm allen key.



Up/Down +/-3mm In/Out +/-2mm Left/Right +/-2mm

Open-out doors are fitted with concealed grub screws. The grub screws engage into a groove in the hinge pin; this stops the hinge pin from being removed. The grub screws are only accessible when the door is in the open position.





**Bull Ring Knockers**

**Stainless Steel Bull Ring Knocker**



**Bolt through fixing on the knocker and the striker**

**Architectural Bull Ring Knocker**




**Bolt through fixing on the knocker**

**The striker is face fixed**

**Round Knob**

**Stainless Steel Knob**







## Door Pull

### Stainless Steel Door Pull

#### External



#### Internal



## Cat Flap



### Magnetic Cat Flap Available in White and Brown

#### Magnetic Lock

The magnetic operation requires no batteries the cat simply wears a collar key which is then used to open the locking mechanism of the cat door. Although not 100% secure (no cat flap is) this does help to keep out unwanted strays and other small animals.

#### 4-way Locking

The 4-way latch offers the ultimate in flexibility. Set the cat flap to open, closed, in only or out only.



### Manual Cat Flap Available in White and Brown


#### 4-way Locking

The 4-way latch offers the ultimate in flexibility. Set the cat flap to open, closed, in only or out only.

### Door Styles available with a cat flap:

- Aspen
- Stable spy view
- Stable view light
- Cottage spy view
- Cottage view light
- T & G 5
- Indiana
- Dakota

### Cut out positions



## Restrictor Detail



### AV-SLDR-A Open Out Restrictor

Door restrictors are designed to provide adjustable limitation to the door movement and allow an opening aperture of maximum 90°.


Features and Specifications:

- Tested to 100,000 cycles
- Corrosion resistance Grade 4 in accordance with BS EN1670:1998

Top edge of door machined off 3.7mm to allow for the restrictor arm.



Installed 100mm from the corner of the frame on the hinge side.



## Furniture Colour Options



Polished chrome matches polished stainless.  
Polished gold matches gold stainless.  
Graphite matches brushed stainless.  
Midnight black, black stainless and wrought iron are all slightly different in colour finish.

	Polished Chrome	Graphite	Polished Gold	Midnight Black	White	Wrought Iron	Brushed Stainless	Polished Stainless	Black Stainless	Gold Stainless
Lever Handle	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Pad Handle	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
D Handle	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Twist Lever Handle	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Arched Lever Handle	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
European Rose Handle	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Curved Rose Handle	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Finger Pull	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Escutcheon	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Standard Letterplate	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Stainless Letterplate	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
TS008 Letterplate (Matching)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Sideframe Letterplate (Black outer)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Contemporary Letterplate	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Architectural Letterplate	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Victorian Centre Knob	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Urn Knocker	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Spy View	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Architectural Knocker	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Numerals	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Contemporary Numerals	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Bull Ring Knocker	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Architectural Bull Ring Knocker	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Square Centre Knob	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Round Bar Handle 600 900 1200	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Offset Round Bar Handle 1200	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Square Bar Handle 1200	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Square Bar Handle 900	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Offset Square Bar Handle 1200	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Mitred Bar Handle 900	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

**Furniture Colour Options**



Polished chrome matches polished stainless.  
 Polished gold matches gold stainless.  
 Graphite matches brushed stainless.  
 Midnight black, black stainless  
 and wrought iron are all slightly  
 different in colour finish.

- Yale Latch
- Yale Finger Pull
- Slide Bolt
- Door Chain
- Hinges
- Cylinder
- Cylinder with thumbturn


	Polished Chrome	Graphite	Polished Gold	Midnight Black	White	Wrought Iron	Brushed Stainless	Polished Stainless	Black Stainless	Gold Stainless
Yale Latch	✓	✓	✓							
Yale Finger Pull	✓	✓	✓							
Slide Bolt	✓	✓	✓							
Door Chain	✓	✓	✓							
Hinges		✓	✓	✓	✓					
Cylinder		✓	✓							
Cylinder with thumbturn		✓	✓							

**Furniture positions**


**Contemporary Knocker**



















## Architectoral Knocker





















## Bull Ring Knocker








## Architectural Bull Ring Knocker





## Urn Knocker





Round and Square Door Knobs




STV-FG 2060 M2



**Drawing Description:**  
 Dimensional Details Of Winkhaus'  
 Standard STV Two Hook  
 Residential Multi-point Door-lock  
 System on a F20 rail.



**Drawing Description:**  
Dimensional Details Of Winkhaus'  
Standard STV Four Hook  
Residential Multi-point Door-lock  
System on a F20 rail.



When the door closes this pin is pushed back which throws the hooks out instantly securing the door from the outside.

### AV2 with Lever/ Fixed D Handle

#### Locking from the inside

- Closing the door automatically throws the top and bottom hooks making the door instantly weathered and secure from the outside.
- The handle can still be operated from the inside for instant exit.
- Insert the key and rotate one revolution to deadlock the door. This throws the central deadbolt and blocks the handle from operating. The door is now fully weathered and secure.

#### Unlocking from the inside

- Insert the key and rotate one revolution. This retracts the central deadbolt and allows the handle to be operated. The door remains weathered and secure from the outside.
- Depress the handle to retract the top and bottom hooks and open the door.

#### Locking from the outside

- Closing the door automatically throws the top and bottom hooks making the door instantly weathered and secure.
- Insert the key and rotate one revolution to deadlock the door. This throws the central deadbolt and blocks the internal handle from operating. The door is now fully weathered and secure.

#### Unlocking from the outside

- Insert the key and rotate one revolution. This retracts the deadbolt.
- Turn the key a further 45 degrees to retract the top and bottom hooks and open the door.



Instant Lock Heritage Plus

Cylinder height centre is 1395mm from the bottom of the door sash.

The lock mechanism has 2 hooks, a central latch and a high-level cylinder position.

This is fitted with either a finger pull, or an escutcheon and a thumbturn internally.

The magnetic triggering of the automatic locking reduces stress marks on the door frame and dampens the closing noise of the automatic locking system.

The magnetic trigger and hook design also improves the reliability of the product, as it can work with slightly larger tolerances which can accommodate any slight door/frame movement over time.

Instant Locking

The Heritage plus system is an instant multi-point locking system with independently acting hooks.

The action of closing the door fully secures the door. There is no further action needed to lock the door.

To open the door the hooks and latch are retracted manually using a key or thumbturn, you are only required to turn a quarter of a turn.

**Magnetic Switch Latch.** (Different to standard switch latch)

UP position

When the switch latch is in the **UP** position, the door instantly locks upon closing. A key is required to regain entry to the property. The door can be opened internally with the thumbturn.

DOWN position

When the Switch Latch is in the **DOWN** position, no key is required allowing you to regain entry to the property and the door can open or close freely.

The door cannot be locked with a key or thumb-turn when the switch latch is in the down position. To lock the door move the switch latch into the up position and then close the door to lock.

The Heritage lock is a Slam Shut lock, so it is important this door is installed to exacting specifications.

**To ensure the lock functions as required, the following must be met.**

HEAD GAP

The head gap should be 4mm and parallel the full width of the door.  
Tolerance +/- 0.5mm


LOCK SIDE GAP

The lock side gap should be 4mm and parallel the full height of the door.  
Tolerance +/- 0.5mm

VIEWING GAP

The viewing gap should be parallel the full height of the door.  
Tolerance +/- 0.5mm

Routing details for Instant Lock Heritage plus



## Switch Latch



### Up Position

When the Switch Latch is in the **UP** position a key is required to gain entry to the property. Don't get caught out and **lock yourself out**.

For total security, the key or thumbturn still needs fully engaging to ensure the hook locks are secured in place.



### Down Position



When the Switch Latch is in the **DOWN** position no key is required allowing you to gain entry to the property and the door can **open or close freely**.

For total security, the key or thumbturn still needs fully engaging to ensure the hook locks are secured in place.



Unlike the magnetic switch latch fitted to the Heritage Plus lock the door can be locked in the down position.

## Electric Latch Release

### Fail **SAFE** Electric Latch Release (no power)




### Fail **SECURE** Electric Latch Release (no power)



### Technical Details (for Both Options)


Handing	Universal
potential	12 V DC
Adjustable latch (FF, FaFix®)	Yes
Fail-unlocked	Yes
Rated operating voltage tolerance range	± 1 V
Rated resistance	60 Ohm
Current consumption DC (50% Residual ripple)	225 mA
Current consumption DC (stabilised)	200 mA
Break-in resistance	3000 N
Height	90 mm
Width	16 mm
Operating temperature range	-15 °C to +40 °C
Max. keeper pre-load DC (50% residual ripple)	10 N
Max. latch preload DC (stabilised)	10 N
Depth	28 mm
Material housing	Zinc die-cast
Latch material	Zinc die-cast
Material surface-mounted attachment	MESSING





## Cylinder

### 3 Star Cylinder



SACRIFICIAL SECTION







The cylinder must be installed with the sacrificial section to the external of the property.

#### FEATURES:

- SS312 Sold Secure Diamond Grade
- 3 Star British Kitemark - TS007:2014 (KM 586153)
- Secured by Design Accredited (Police preferred specification)
- Patented Snap Secure Technology
- Pick, Drill & Bump Resistant
- 6 Trap Pins for advance pick resistance
- 10 Anti-drill pins
- Three Rockdoor branded keys per cylinder
- Keyed alike key/key pairs are available ex stock
- Size 40mm/40mm

The key must be removed from the cylinder for the full security features to be enabled.

## Cylinder Installation



## Emergency Exit Door

Rockdoors emergency exit door is customised with a hardware solution that allows the door to be opened quickly and easily in a 'panic' situation. This includes typical emergency exits used in public places such as shopping centres, schools, cinemas and commercial use buildings.



### External Operation

**Lock:** To lock the door from the outside, the key provided must be used to wind out the bolts into position. If the door is locked from the inside the external handle will not open the door.

**Unlock:** To open the door from the outside, use a key to unwind the bolts and then open the door using the external lever handle.



### Internal Operation

**Lock:** To lock the door from the inside, use the thumbturn to wind out the bolts.

**Unlock:** To open the door from the inside, push firmly down on the push bar which will instantly retract the locks and allow the door to open freely. This will open the door regardless of whether the door has been left in the locked or unlocked position.

## High Security, Quick Escape

Our emergency exit door ensures buildings can remain extremely secure, whilst providing a quick and safe method of exit to members of the public.

## When to use Emergency Exit Doors

In accordance with EN1125, Rockdoor emergency exit doors should be used as a single door set that members of the public will have access to. The high concentration of people makes 'panic' situations more likely in public buildings. The occupants will not necessarily be familiar with the locations of the emergency exits, or how to open them. They therefore need to be able to open the doors intuitively using the horizontal push bar.

Rockdoor emergency exit doors, in accordance with EN 1125, are always outward-opening doors. All emergency exit doors must bear the CE mark.

## Door Specification:

- 1. Door styles**  
All door styles except stable doors and double doors.
- 2. Glazing**  
P1A compliant glass (6.8mm Laminated)
- 3. Outer frame**  
72mm Rehau Outer frame or 52mm Rehau Outer frame
- 4. Reinforcing**  
Security Mesh
- 5. Handle**  
Standard lever/lever handle or Bar Handle
- 6. Hinges**  
Standard 3D Rockdoor hinge
- 7. Lock**  
Winkhaus 2 hook lock
- 8. Cylinder**  
Standard Rockdoor 3 star cylinder
- 9. Keeps**  
Standard Rockdoor full length keeps
- 10. Threshold**  
Aluminium low threshold
- 11. Letterplate**  
Must be TS008 compliant



## Methods of test.

### 1. Operating Forces

The operating forces acting on the sample were determined by the methods given in BS EN 12046-2:2000.

### 2. Air Permeability

The air permeability of the sample was determined by the method given in BS 6375-1:2015.

### 3. Watertightness

The watertightness of the sample was determined by the method given in BS 6375-1:2015.

### 4. Wind Resistance

The wind resistance of the samples was determined by the methods (P1 and P2) given in BS 6375-1:2015.

### 5. Repeat Tests

After testing for resistance to wind loading (P1 and P2) the air permeability test was repeated.

### 6. Wind Resistance

The wind resistance of the samples was determined by the method (P3) given in BS 6375-1:2015.

### 7. Resistance to Vertical Loads

The resistance to vertical loads test was carried out using the method given in BS EN 947:1999.

### 8. Resistance to Static Torsion

The resistance to static torsion test was carried out using the method given in BS EN 948:1999.

### 9. Soft and Heavy Body Impact

The resistance to soft and heavy body impact was carried out using the method given in BS EN 949:1999.

### 10. Hard Body Impact

The resistance to hard body impact was carried out using the method given in BS EN 950:1999.

Secured by Design (SBD) is the official police security initiative that works to improve the security of buildings and their immediate surroundings to provide safe places to live.

For Rockdoor to meet the specification they should be fitted with:

- 1 **P1A Compliant glass (6.8mm laminated)**
- 2 **Security mesh.**
- 3 **Letterplates must conform to requirements of TS008.**



For solid door styles with no glass, please refer to the Clear Backing glass section for the doors energy rating

Door Style

Door Style	CLEAR BACKING GLASS				OBSCURE BACKING GLASS			
	72mm threshold	52mm threshold	Alli threshold open out	Alli threshold open in	72mm threshold	52mm threshold	Alli threshold open out	Alli threshold open in
Aspen	A	A	A	A	A	A	A	A
Astoria	A	A	A	A	A	A	A	A
Arcacia	A	A	A	A	A	A	A	A
Campus	A	A	A	A	A	A	A	A
Carolina	A	A	A	A	A	A	A	A
Classic	B	B	B	B	B	B	B	B
Colonial	A	A	A	A				
Cottage spy view	A	A	A	A	A	A	A	A
Cottage view light	A	A	A	A	A	A	A	A
Dakota	A	A	A	A				
Diamond	A	A	A	A	A	A	A	A
Dune Retreat	A	A	A	A	A	A	A	A
Dune Vision	B	B	B	B	B	B	B	B
English cottage	A	A	A	A	A	A	A	A
Georgia	B	B	B	B	B	B	B	B
Hudson	A	A	A	A	A	A	A	A
Illinois	B	B	B	B	B	B	B	B
Indiana	A	A	A	A				
Jacobean	B	B	B	B	B	B	B	B
Kentucky	B	B	B	B	B	B	B	B
Manhattan	A	A	A	A	A	A	A	A
Montana	A	A	A	A	A	A	A	A
Newark	A	A	A	A	A	A	A	A
Portland	B	B	B	B	B	B	B	B
Philadelphia	A	A	A	A	A	A	A	A
Regency	A	A	A	A	A	A	A	A
Stable diamond view	B	B	B	B	B	B	B	B
Stable spy view	B	B	B	B	B	B	B	B
Stable view light	B	B	B	B	B	B	B	B
Tennessee	B	B	B	B	B	B	B	B
Tongue and groove 5	A	A	A	A	A	A	A	A
Vermont	A	A	A	A	A	A	A	A
Virginia	B	B	B	B	B	B	B	B
Vogue	B	B	B	B	B	B	B	B
Warwick	A	A	A	A	A	A	A	A
Windsor	B	B	B	B	B	B	B	B

### Energy Ratings

### Condensation

#### WHAT CREATES CONDENSATION?

##### Water vapour content in the air

This is produced by normal living activities such as washing, cooking, bathing, etc., and can be controlled using extractor fans, cowlings, and ventilation at appropriate places.

##### Inside room temperature

This can be controlled to some extent, thereby maintaining a higher surface temperature of items in the room, and by increasing the air temperature to enable it to hold more water vapour without condensing.

##### Coldest surface in the home

Modern aids to home comfort have created rooms which are warmer, but which often have less ventilation and fewer air changes. The result is that the water vapour produced by normal living activities, is no longer able to escape up the chimney or through door jambs, window joints and other outlets.

In certain circumstances, all these aids to comfort combine to create ideal conditions for the formation of condensation, which could form on the coldest surfaces within the home.

##### What is the coldest part of a Rockdoor.

Thermally efficient PVC-U skins, a 50mm thick sash, S-Glaze, performance gaskets, Multi chamber PVC-U door frame and high-density polyurethane foam work together to achieve industry leading thermal performance ratings.

However, there are areas on a Rockdoor that when the outside temperatures are low can be colder than other areas, especially if the internal temperatures are also low.

These areas are the locking cylinder, the hinges, Aluminium thresholds, and the area where the aluminium reinforcement is inside the door (around the perimeter).

If the conditions for condensation are present, it can start to appear on the above parts of the door.

## Examples of where water vapour comes from

**Breathing:** Two sleeping adults produce approximately 1 litre of moisture in 8 hours, which is absorbed as water vapour into the atmosphere.

**Cooking:** Steam clouds can be seen near saucepans and kettles, and then seem to disappear. The clouds have been absorbed into the atmosphere. The heat source itself may be a source of water vapour, e.g. an average gas cooker could produce approximately 1 litre of moisture per hour.

**Washing up:** Vapour clouds given off by hot water are rapidly absorbed into the atmosphere. Bathing, laundry, and wet outer clothing: these are often major sources of water vapour in the home.

**Heaters:** A flueless gas heater can produce up to 350cc of moisture per hour. Paraffin heaters produce 4 litres of moisture for every 3.5 litres of fuel burned.

**Indoor plants:** A frequently unrecognised but nevertheless significant source of water vapour.

**New property/building work:** The bricks, timber, concrete, and other materials in an average 3-bedroomed house absorb about 7,000 litres of water during construction. Much of this is dissipated into the indoor atmosphere during the drying out period.

## How do you reduce the condensation in the home?

- It is important to remove excess moisture by ventilating rooms.
- A room can be ventilated without making draughts or causing it to become cold. One way to do this is to open the window slightly or use the trickle vent if fitted.
- By opening windows or ventilating your home it may appear that you are losing some heat, but what you are doing is allowing warm moisture laden air to escape and permitting cool dry air to enter your home. Dry cool air is cheaper to heat than warm moist air.
- Provide natural ventilation through an opening section of the window, through a proprietary ventilating unit, or through an airbrick. Check that trickle vents are in the open position.
- Where there is no open fire, or where existing flues have been blocked off (and cannot be unblocked), ensure that wall vents are fitted and kept clear.
- Open at least one window in each room for some part of the day to permit a change of air. Ensure permanent ventilation of all rooms where gas and oil heaters are used. NOTE: This is a statutory requirement which will be monitored by the heating engineer.

- Fix hoods over cookers and other equipment producing steam and ventilate them to the outside air.
- Ensure that bathrooms and kitchens are ventilated in accordance with National Standards.
- Draught proof internal doors and keep them closed, to prevent transfer of air with high water vapour content from the main moisture producing rooms –kitchens, bathrooms, and drying rooms. It should be borne in mind that water vapour does not remain in the room where it is first generated but tends to migrate to other parts of the home generally where the rooms are colder.
- Increase slightly the air temperature within the room where the condensation occurs.
- In cold weather, keep some form of heating on permanently in the room where the condensation occurs.
- In winter months to help with atmospheric moisture control the introduction of a dehumidifier will help maintain a healthy living space and help reduce the chances of condensation forming on cooler surfaces.

## Summary

Whilst we pride ourselves on creating a thermally efficient industry leading door, it is important we raise awareness to customers on the issues experienced by all window and door manufacturers. The nature of modern-day living has created cosy warm homes where moist damp air is stored, but it is this damp air that manifests itself as condensation unless the air is dealt with and removed from the property. This issue is highlighted by the government's building regulations that now stipulate the use of trickle vents on all newly installed windows, both in new build house and replacement windows.




## Replacement Parts

### Replacement Parts

To ensure you receive the correct replacement part, you firstly need to find the Rockdoor production number of the door that requires parts. This can be found on the hinge side of the inner frame and is a 6 or 7 digit reference number. Contact can then be made to GAP's customer service team ([customerservice@gap.uk.com](mailto:customerservice@gap.uk.com)) who can help you.

Our team can then use our systems to find the correct part for the door and arrange for its delivery to the depot.

With lots of parts used to construct the door, it's useful to make sure we have the correct part, so please refer to the illustration below.



The Original **Composite Door**.

Rockdoor must be installed in-line with the five star installation guide. ★★★★★